

## 3 easy steps for your dowel joints

1



Place the jig onto the board, fix the end stop and tighten the workpiece. Set the bore depth and clamp the boring adaptor on your drilling machine. Bore vertical holes.

2



Fasten the jig on the other element, fix the end stop and set the bore depth. Bore horizontal holes.

3



Now insert the dowels with glue into the holes and join both elements

3



As an alternative, use through hole bits and screw the elements together.